




DUO-DIAL Electric Water Timer



Time Saving • Water Saving • Money Saving

RUN TIME

To set your run time, turn the dial to the required watering time, from 1 to 120 minutes.

TIME DELAY FEATURE

You can delay your watering start time using the Time Delay Feature. Use the point of the pen to depress the button for each hour you want to delay watering. You can delay watering in 1 hourly intervals only, up to a maximum of 12 hours. So to delay watering for 3 hours, depress the Time Delay button 3 times.

LOW BATTERY INDICATOR

The Low Battery Indicator light flashes continuously while the Batteries still have sufficient power to operate the timer.

When the battery power is low the Low Battery Indicator will remain on, and the valve will be shut off. The light will go out when the battery is completely flat.

HOW TO OPERATE

1. Install and only use 2 new AA alkaline Batteries in the battery compartment (Using old batteries will decrease the overall operational time of the timer).
2. Test to ensure the unit is operational. simply turn the RUN TIME dial to the "ON" position. Within a few seconds you should hear the timer mechanism operate. Repeat for the second outlet.
3. Program your timer prior to connecting to the tap.
4. Use the FREQUENCY dial to determine how often you want to water.
5. Use the RUN TIME dial to determine how long you want to water.
6. Fit the 3/4" tap connector or the 1" adaptor to your garden tap. If using the 1" adaptor, attach it directly to the tap.
7. Loosen the collar until the fitted 3/4" tap connector is loose. Then holding the timer steady with one hand, fit to the tap.
8. Hand tighten the collar until secure.

DO NOT OVERTIGHTEN.

9. The water can now be turned on.

Please note: Watering will commence when the first "frequency cycle" you have set has passed.

For example if your Frequency Dial is set to 1 hour, the first watering cycle will commence one hour after you have set the program...and continue hourly thereafter.

- Using ON will allow the water to flow from the tap.
- Using OFF will prevent water flowing from the tap, even if the tap is on.

MAINTENANCE

Make sure you only use new Alkaline batteries. Keep clear of dirt and debris. Ensure water is not accidentally sprayed into battery compartment.

Timer cannot be reassembled if taken apart. Disassembling will void all warranties.

PERFORMANCE SPECIFICATIONS

Water pressure : Maximum up to 150 psi (10 bar).

If operating in a higher water pressure area, use a pressure reducer.

Batteries : 2 x AA Alkaline.

Use with cold water only.

TROUBLE SHOOTING

- If batteries are running low the valve will close automatically.
- Ensure that the RUN TIME dial is not set to OFF.
- Check that the Frequency selected is longer than the RUN TIME.
Eg. do not set a 120 minute run time and a 2 hour frequency.
- Make sure the tap is turned on.

Your Simple Set DUO-DIAL, Twin Automatic Tap Timer is two independent tap timers in one unit. It gives you all the convenience of set and forget garden watering for two areas of your garden. Just select how long and how often you want to water your garden and the Simple Set DUO-DIAL, Twin Automatic Tap Timer will do the rest.

KEY FEATURES

- Two independent tap timers in one compact unit
- Connects straight to the tap
- Time delay feature
- Low battery indicator
- Easy to use
- Simple to install
- Time saving
- Runs on 2 x AA alkaline batteries (no wiring required)
- Includes tap adaptor, to fit 3/4" and 1" taps
- Guaranteed for 12 months
- Can be set to run up to 24 times per day per outlet
- Can be set to run up to 2 hours at a time per outlet
- Durable body
- Water resistant cover

WATERING FREQUENCY

Select every 1, 2, 3, 4, 6, 8, 12, 24, 48 or 72 hour,
or every week

WATERING RUN TIME

Select 1, 3, 5, 10, 15, 20, 30, 60, 90 or 120 minutes

TO PROGRAM

Once attached to tap simply select your watering frequency
and your run time.

The dials can be turned both clockwise and anti-clockwise
without damaging the mechanism.

WATERING FREQUENCY

- To set watering twice daily - Select 12
- To set watering daily - Select 24
- To set watering every second day - Select 48
- To set watering once a week - Select week